



DATE 21 April, 2014

No. V-70002

Messrs. Non Invasive Blood Pressure Monitors

SPECIFICATION

AP3xx-044KG-NIBP

AG3xx-044KG-NIBP

AP3xx-050KG-NIBP

Model: AG3xx-050KG-NIBP

Project:

Distributed by:
Servoflo Corporation

Distributor:

75 Allen Street
Lexington, MA 02421
781-862-9572 info@servoflo.com

Reference:

Fujikura Ltd.

Table of Contents

1.	General	2
2.	Principle	2
3.	Device lineup	2
4.	RoHS.....	2
5.	Block Diagram and Pin Connections	3
6.	Device Name Code.....	4
7.	Absolute Maximum Rating	5
8.	General Specifications	5
9.	Electrical Characteristics.....	6
10.	Output versus Input Pressure.....	8
11.	Transfer Function.....	9
12.	Single Point Pressure Threshold Detection	10
13.	Operating Sequence	11
14.	Device Marking	12
15.	Soldering	13
16.	Dimensions and Weights	13
17.	Ordering Information.....	14
18.	Tape & Reel Information	14
19.	Footprint for PCB (for Reference).....	15
20.	Notes.....	16
	Appendix: Dimension Drawing.....	17
	9-772-001 APxxN.....	17
	9-772-002 APxxR	18
	9-772-003 AGxx3.....	19
	9-772-004 AGxx6.....	20

Table shown below is revision records of this specification

Rev.				
Est.	21 April, 2014	Y.Uchiumi		
	Date	Name	Comment	Mark

1. General

This document describes the specifications of Fujikura Pressure Sensors, Type of AP3xx-044KG-NIBP, AG3xx-044KG-NIBP, AP3xx-050KG-NIBP and AG3xx-050KG-NIBP. This product is modified for Non-Invasive Blood Pressure Monitors.

2. Principle

Fujikura Pressure Sensor is composed of a silicon piezoresistive pressure sensing chip and a signal conditioning integrated circuit. The low-level signal from the sensing chip is amplified, temperature compensated, calibrated, and finally converted to a high-level output signal that is proportional to the applied pressure.

3. Device lineup

This device has the following lineup.

Model	Pressure Type	Supply Voltage	Accuracy	0	Pressure Range (kPa)	
					43.996 kPa (330 mmHg)	49.996 kPa (375 mmHg)
AP3 or AG3	Gauge	5.0 Vdc or 3.3 Vdc	± 2.5 mmHg			


Features

- Low Noise
- Single Point Pressure Threshold Detection

4. RoHS

This device is compliant with the Restriction of the use of certain Hazardous Substances in Electrical and Electronic Equipment (RoHS).

5. Block Diagram and Pin Connections




Pin Assignment		Pin No.	Pin Name	I/O	Type	Function	
AP3	AG3	4 5 6 Index 4 5 6 Index 3 2 1 Pipe	1	VSS	-	-	Common voltage connection
			2	VOUT	O	Analog	Analog output
			3	VDD	-	-	Power supply connection
			4	VSS	-	-	Common voltage connection
			5	PDET	O	Digital	Pressure threshold detection
			6	PTH	I	Analog	Pressure threshold input

Notes:

- *1) Both Pin 1 and Pin 4 must be connected to VSS.
- *2) Put a 1.0 μF capacitor between Pin3 (VDD) and VSS.
- *3) Put a resistor in series with Pin6 (PTH), when inputting threshold voltage (Vth). The minimum resistance value is 30 $\text{k}\Omega$.
- *4) If an application does not use Pressure Threshold Detection, put a pull-up resistor between Pin6 (PTH) and VDD, or put a pull-down resistor between Pin6 (PTH) and VSS. The minimum resistance value is 30 $\text{k}\Omega$.

6. Device Name Code

The Device name code is consisted of Sensor code, Pressure code, Custom ID and Packing style. For the exact ordering device number, please refer to Chapter 17 Ordering Information.



7. Absolute Maximum Rating

Item	Symbol	Rating	Unit
Load Pressure	Pmax+	+99.992	kPa
		+750	mmHg
Supply Voltage	VDDmax	6	Vdc
Operating Temperature	Topt	-40 ~ +105	deg. C
Storage Temperature	Tstg	-40 ~ +105	deg. C

Note:

*1) Absolute maximum ratings are the limits that the device will withstand without damage.

8. General Specifications

item	Condition		Symbol	Rating			Unit	
				Min.	Typ.	Max.		
Supply Voltage	Sensor Code	AP30x, AG30x	VDD	4.75	5	5.25	Vdc	
		AP31x, AG31x		3.135	3.3	3.465		
Type of Pressure			-	Gauge pressure			*2	
Pressure Range	Pressure Code	044KG	Popt	0	-	+43.996	kPa	
				0	-	+330	mmHg	
		050KG		0	-	+49.996	kPa	
				0	-	+375	mmHg	
Pressure Media			-	Non-corrosive gases			*4	
Compensated Temperature			-	0	-	+60	deg. C	
Operating Humidity	Non-condensing		Hopt	30	-	85	%RH	
Storage Humidity	Non-condensing		Hstg	30	-	85	%RH	
Dielectric Strength			-	-	-	1	mA	
Insulation Resistance			-	100	-	-	MΩ	

Notes:

*1) Output voltage (Vout) is not perfectly ratio-metric with the power supply voltage (VDD).

*2) Gauge pressure is defined as the difference between the pressure applied and atmospheric pressure.

*3) 1 mmHg equals 0.133322 kPa. Pressure range (Popt) is defined as the measurable pressure range of the device.

*4) Ensure the pressure media contains no particulates. The device is not compatible with liquids.

*5) Please also refer to Chapter 11 Transfer Function.

*6) Do not wet the device with dew.

*7) Dielectric strength is defined as the leakage current between all pins and the package with AC500, 1 minute.

*8) Insulation resistance is defined as the resistance value between all pins and the package with DC500V.

9. Electrical Characteristics

Load Resistor $RL=\infty$, Ambient temperature $Ta=25\text{deg. C}$

Item	Condition	Symbol	Rating			Unit
			Min.	Typ.	Max.	
Sensor Code: AP30x, AG30x (VDD = 5Vdc)						
Offset Voltage	Min. Popt	Voff	0.1	0.2	0.3	V
Full Scale Voltage	Max. Popt	Vfs	4.6	4.7	4.8	V
Span Voltage	Min. to Max. Popt	SV	4.47	4.5	4.53	V
Supply Current		Ic	-	-	6	mAdc
Sensor Code: AP31x, AG31x (VDD = 3.3Vdc)						
Offset Voltage	Min. Popt	Voff	0.2	0.3	0.4	V
Full Scale Voltage	Max. Popt	Vfs	2.9	3.0	3.1	V
Span Voltage	Min. to Max. Popt	SV	2.67	2.7	2.73	V
Supply Current		Ic	-	-	5	mAdc
Accuracy	0 to 60 deg. C, Min. Popt to 300mmHg	Error1	-2.5	-	+2.5	mmHg
	0 to 60 deg. C, >300mmHg	Error2	-5.0	-	+5.0	mmHg
Temperature Offset Error	0 to 60 deg. C	TSO	-0.03	-	+0.03	V
Response Time	for reference	tr	-	1	-	msec.
Noise Floor	Min. Popt, with LPF & HPF	NF	-	-	0.033	mmHg p-p
Load Resistor	VOUT - VSS or VDD - VOUT	RL	9.5	-	-	kΩ
Load Capacitance	VOUT - VSS	CL	-	-	50	pF
Sampling Frequency		fs	-	8.33	-	kHz


Notes:

- *1) Offset voltage (Voff) is defined as the output voltage at minimum Popt.
- *2) Offset error is calibration error of offset voltage in production. It does not include Long term offset drift. It would be suggested that application has Auto-zeroing function.
- *3) Full scale voltage (Vfs) is defined as the output voltage at maximum Popt.
- *4) Output span voltage (SV) is defined as the voltage difference between Offset voltage (Voff) and Full scale voltage (Vfs).
- *5) Supply Current (Ic) is increased depending on the value of Load resistor (RL).
- *6) Accuracy consists of the following:
 Non-linearity
 Pressure hysteresis
 Sensitivity calibration error
 Temperature errors of sensitivity over the temperature range 0 to 60 deg. C
Exclude offset error and temperature errors of offset voltage over the temperature range 0 to 60 deg. C.
- *7) Output voltage per 1 mmHg is as below:


$$\frac{SV}{\text{Max. Popt}} \text{ (mV/mmHg)}$$

Sensor Code	Pressure Code	044KG	050KG
AP30x, AG30x		$4500(\text{mV}) / 330(\text{mmHg}) = 13.636(\text{mV/mmHg})$	$4500(\text{mV}) / 375(\text{mmHg}) = 12(\text{mV/mmHg})$
AP31x, AG31x		$2700(\text{mV}) / 330(\text{mmHg}) = 8.181(\text{mV/mmHg})$	$2700(\text{mV}) / 375(\text{mmHg}) = 7.2(\text{mV/mmHg})$

- *8) Temperature offset error (TSO) is defined as the output voltage drift by temperature.
- *9) Response time (tr) is defined as the time for the change in output voltage from 10% to 90% or from 90% to 10% of its final value when the input pressure makes a step change.




- *10) Noise floor (NF) is defined as the output voltage at 0mmHg that is filtered by HPF and LPF. This test is not processed in production.



Test sequence of Noise Floor

- *11) Noise floor (NF) is increased depending on input pressure.
- *12) Do not put Load capacitance (CL) that is over 50pF between VOUT and VSS.
- *13) Output voltage (Vout) is sampled and held by the internal sampling / hold block. Sampling frequency (fs) is 8.33 kHz. The output voltage is changed stepwise every approximately 120 microseconds.



10. Output versus Input Pressure

Sensor Code	Pressure Code	
	044KG	050KG
AP30x AG30x	<p style="text-align: center;">VDD = 5.0 Vdc Temp. = 0 to 60 °C</p> <p style="text-align: center;">Input Pressure</p>	<p style="text-align: center;">VDD = 5.0 Vdc Temp. = 0 to 60 °C</p> <p style="text-align: center;">Input Pressure</p>
AP31x AG31x	<p style="text-align: center;">VDD = 3.3 Vdc Temp. = 0 to 60 °C</p> <p style="text-align: center;">Input Pressure</p>	<p style="text-align: center;">VDD = 3.3 Vdc Temp. = 0 to 60 °C</p> <p style="text-align: center;">Input Pressure</p>

11. Transfer Function


$$V_{out} = VDD \times ((P \times \alpha) + \beta) \pm (\text{Pressure Error} \times \text{Temperature Error Multiplier} \times \alpha \times VDD)$$

Parameters:

Sensor Code	Parameter Pressure Code	VDD (*1)	P	α	β	Pressure Error
AP30x	044KG	5.0±0.25 V	0 ~ +330 mmHg	3/1100	1/25	2.5 mmHg
AG30x	050KG		0 ~ +375 mmHg	3/1250		
AP31x	044KG	3.3±0.165 V	0 ~ +330 mmHg	3/1210	1/11	2.5 mmHg
AG31x	050KG		0 ~ +375 mmHg	3/1375		

Note:

*1) Output voltage (Vout) is not perfectly ratio-metric with the power supply voltage (VDD).



12. Single Point Pressure Threshold Detection

AP3 and AG3 have a voltage detector. Output voltage (VOUT) and threshold voltage from PTH are inputted into the detector. Detector's output will be changed when VOUT reaches a threshold voltage.


Ambient temperature Ta=25 deg. C

Item	Condition	Symbol	Rating			Unit
			Min.	Typ.	Max.	
Type of Output		PDET	CMOS output			*2
Threshold Input voltage	PTH	V _{th}	0.1*VDD	-	0.9*VDD	V
Input Impedance	PTH	Z _{in}	1	-	-	MΩ
Output voltage	V _{OUT} < V _{th}	V _{OH}	0.9*VDD	-	-	V
	V _{OUT} ≥ V _{th}	V _{OL}	-	-	0.1*VDD	V
Pressure Hysteresis		Phys	-	0.05*VDD	-	V
Detection Time		T _{detr}	-	150	-	μsec
Non Detection Time		T _{detf}	-	150	-	μsec


Notes:

*1) Do not control any device directly using this function. Because there is indeterminate status during the supply voltage rises.


*2) Equivalent circuits of PDET and PTH are as below:



*3) Please also refer to the following timing chart.




13. Operating Sequence



Notes:

- *1) Before supply voltage reaches $0.8*VDD$, the status of VOUT, PDET and PTH are indeterminate.
- *2) After reaching $0.8*VDD$, initializing process is started. At initializing process, PDET is fixed $0.9*VDD$ and over, and VOUT is fixed $0.1*VDD$ and under.

14. Device Marking



Items	Marking	
Production Lot		
Y	Last digit of Production year	0~9
M	Production month	1, 2, 3 ~ 8, 9, X=Oct., Y=Nov., Z=Dec.
DD	Production date	01~31
Sensor Code		*1
AP30x		AP30
AP31x		AP31
AG30x		AG30
AG31x		AG31
Pressure Code		
044KG		044K
050KG		050K
Custom ID		NIBP

Note:

*1) Pin direction of AP3 and Port length of AG3 is not marked on the face plate.

15. Soldering

Process	Sensor Code	Condition																
Hand soldering	AP3xx	Soldering iron temperature: 350 deg. C max. Soldering time: 3 seconds max. / each pin	*1, 2															
Wave soldering	AP3xR	Soldering bath temperature: 260 deg. C max. Soldering time: 5 seconds max.	*1, 2															
Reflow soldering	AG3xx	<p style="text-align: center;">Soldering Profile</p> <table border="1" style="margin-left: auto; margin-right: auto;"> <tr> <td>A</td> <td>Ramp up</td> <td>2 to 4 deg. C / sec.</td> </tr> <tr> <td>B</td> <td>Pre-heating</td> <td>150 to 180 deg. C 60 to 120 sec.</td> </tr> <tr> <td>C</td> <td>Ramp up</td> <td>2 to 4 deg. C / sec.</td> </tr> <tr> <td>D</td> <td>Heating</td> <td>Above 230 deg. C, 45 sec. max. 245 deg. C max., 10 sec. max.</td> </tr> <tr> <td>E</td> <td>Ramp down</td> <td>2 to 4 deg. C / sec.</td> </tr> </table>	A	Ramp up	2 to 4 deg. C / sec.	B	Pre-heating	150 to 180 deg. C 60 to 120 sec.	C	Ramp up	2 to 4 deg. C / sec.	D	Heating	Above 230 deg. C, 45 sec. max. 245 deg. C max., 10 sec. max.	E	Ramp down	2 to 4 deg. C / sec.	*1, 2, 3, 4
A	Ramp up	2 to 4 deg. C / sec.																
B	Pre-heating	150 to 180 deg. C 60 to 120 sec.																
C	Ramp up	2 to 4 deg. C / sec.																
D	Heating	Above 230 deg. C, 45 sec. max. 245 deg. C max., 10 sec. max.																
E	Ramp down	2 to 4 deg. C / sec.																

Notes:

- *1) NEVER wash the device with any washing liquid. NEVER wash the device with any ultrasonic washing machine.
- *2) Do not put the solder and flux on the device's package.
- *3) Temperature means Surface temperature of the device's package.
- *4) Reflow soldering is within two times.

16. Dimensions and Weights


Refer to the following drawing as attached.

Sensor Code	Dimension Drawing	Weights
AP3xN	9-772-001	approx. 1.4 grams
AP3xR	9-772-002	
AG3x3	9-772-003	approx. 0.3 grams
AG3x6	9-772-004	approx. 0.4 grams

17. Ordering Information

Model	Package	Pressure Range	Supply voltage	Pin direction	Packing	Ordering Device Number	Qty./Packing
AP3	DIP	330 mmHg	5.0 Vdc	Normal	Tray	AP30N-044KG-NIBP	150 Pcs/Tray
					Stick	AP30N-044KG-NIBP-STICK	40 Pcs/Stick
				Opposite	Tray	AP30R-044KG-NIBP	150 Pcs/Tray
					Sticks	AP30R-044KG-NIBP-STICK	40 Pcs/Stick
		3.3 Vdc	Normal	Normal	Tray	AP31N-044KG-NIBP	150 Pcs/Tray
					Stick	AP31N-044KG-NIBP-STICK	40 Pcs/Stick
			Opposite	Opposite	Tray	AP31R-044KG-NIBP	150 Pcs/Tray
					Stick	AP31R-044KG-NIBP-STICK	40 Pcs/Stick
		375 mmHg	5.0 Vdc	Normal	Tray	AP30N-050KG-NIBP	150 Pcs/Tray
					Stick	AP30N-050KG-NIBP-STICK	40 Pcs/Stick
				Opposite	Tray	AP30R-050KG-NIBP	150 Pcs/Tray
					Stick	AP30R-050KG-NIBP-STICK	40 Pcs/Stick
		3.3 Vdc	Normal	Normal	Tray	AP31N-050KG-NIBP	150 Pcs/Tray
					Stick	AP31N-050KG-NIBP-STICK	40 Pcs/Stick
			Opposite	Opposite	Tray	AP31R-050KG-NIBP	150 Pcs/Tray
					Stick	AP31R-050KG-NIBP-STICK	40 Pcs/Stick
				Port Length			
AG3	SMD	330 mmHg	5.0 Vdc	3mm	Tray	AG303-044KG-NIBP	300 Pcs/Tray
					Tape & Reel	AG303-044KG-NIBP-TP	500 Pcs/Reel
				6mm	Tray	AG306-044KG-NIBP	300 Pcs/Tray
					Tape & Reel	AG306-044KG-NIBP-TP	500 Pcs/Reel
		3.3 Vdc	3mm	Normal	Tray	AG313-044KG-NIBP	300 Pcs/Tray
					Stick	AG313-044KG-NIBP-TP	500 Pcs/Reel
			6mm	Normal	Tray	AG316-044KG-NIBP	300 Pcs/Tray
					Stick	AG316-044KG-NIBP-TP	500 Pcs/Reel
		375 mmHg	5.0 Vdc	3mm	Tray	AG303-050KG-NIBP	300 Pcs/Tray
					Tape & Reel	AG303-050KG-NIBP-TP	500 Pcs/Reel
				6mm	Tray	AG306-050KG-NIBP	300 Pcs/Tray
					Tape & Reel	AG306-050KG-NIBP-TP	500 Pcs/Reel
			3.3 Vdc	3mm	Tray	AG313-050KG-NIBP	300 Pcs/Tray
					Stick	AG313-050KG-NIBP-TP	500 Pcs/Reel
				6mm	Tray	AG316-050KG-NIBP	300 Pcs/Tray
					Tape & Reel	AG316-050KG-NIBP-TP	500 Pcs/Reel

18. Tape & Reel Information



19. Footprint for PCB (for Reference)


Sensor Code	Footprint
AP3xN	<p>Footprint diagram for AP3xN sensor. It features six land pads arranged in a 2x3 grid. Above the grid, there are two sets of concentric circles: '6 - $\phi 1.8$ mm' and '6 - $\phi 0.9$ mm'. A dashed circle indicates the outline of the footprint. A note specifies 'Hole for Pressure Port' with a diameter depending on your design. Vertical distances between pads are 2.54 mm, and the total width is 15.2 mm.</p>
AP3xR	<p>Footprint diagram for AP3xR sensor. It features six land pads arranged in a 2x3 grid. Above the grid, there are two sets of concentric circles: '6 - $\phi 1.8$ mm' and '6 - $\phi 0.9$ mm'. A dashed circle indicates the outline of the footprint. Vertical distances between pads are 2.54 mm, and the total width is 15.2 mm.</p>
AG3x3	<p>Footprint diagram for AG3x3 sensor. It features six land pads arranged in a 2x3 grid. Above the grid, there are two sets of concentric squares: '1.4 mm' and '1.7 mm'. A dashed circle indicates the outline of the footprint. Vertical distances between pads are 2.54 mm, and the total width is 9.4 mm.</p>
AG3x6	<p>Footprint diagram for AG3x6 sensor. It features six land pads arranged in a 2x3 grid. Above the grid, there are two sets of concentric squares: '1.4 mm' and '1.7 mm'. A dashed circle indicates the outline of the footprint. It also includes two additional holes labeled '2 - $\phi 1.1$ mm (Holes for Projections)'. Vertical distances between pads are 2.54 mm, and the total width is 9.4 mm. The total height of the footprint is 6.0 mm.</p>

Notes:





- *1) These footprints are for reference. Please evaluate well these footprints, before your mass production.
- *2) When designing your PCB, please also refer to the outline diagrams.

20. Notes

- Fujikura reserves all rights.
- This document has a possibility to be changed without notice.
- Limitation, usage, environment, standard warranty and so on are listed on Fujikura web site.
- Please refer to the latest specifications.




Unless otherwise specified, tolerance: +/- 0.1mm






PART NO.	NAME OF PART	MATERIAL	QUANTITY	REMARKS
第3角法 NAME NUMBER	APXXN Series			
PROJECT NAME: UNITS m m	Outline diagram			
SCALE Free				
DATE OF ISSUE	図面番号 DRAWING NO.			REV. MARK
06/11/2013	9-772-001			◆

MARK	変更 REVISIONS	年月日 DATE
◆		




Unless otherwise specified, tolerance: +/- 0.1mm





PART NO.	NAME OF PART	MATERIAL	NUMBER	REMARKS
第3角法 NAME IN CHINESE		APXR Series		
PROJECT NAME:		Outline diagram		
UNITS mm		Free		
DATE OF ISSUE	圖面番号 DRAWING NO.	REV. MARK	REV. MARK	
06/11/2013	9-772-002			


WORK	REVISIONS	DATE
◇	変更	




Unless otherwise specified, tolerance: +/- 0.1mm



pin 5
pin 6
pin 4
pin 3
pin 2
pin 1




大気圧導入口
Vent hole




PART NO.	NAME OF PART	MATERIAL	QUANTITY	REMARKS
第3角法 Name: AGX X 3 Series	名稱: TITLE			
PROJECT NAME: AGX X 3 Series	單位: UNITS m m			
Outline diagram Free	尺度: SCALE Free			
DATE OF ISSUE: Oct/1/2013	圖面番号: DRAWING NO. 9-772-003			REMARK REV. MARK

MARK	REVISIONS	DATE
◆	変更	年月日



Unless otherwise specified, tolerance: +/- 0.1mm



PART NO.	NAME OF PART	MATERIAL	量数	REMARKS
第3角法 PROJECT NAME:	AG××6 Series Outline diagram			
UNIT OF MEASUREMENT: mm				
SCALE: Free				
DATE OF ISSUE: Oct/11/2013	図面番号 DRAWING NO.: 9-772-004			REMARK REV. MARK
REV. MARK	変更 REVISIONS	年月日 DATE		